

It's...
It's... if you
follow... de...

Thank You!

1 Place 4 pins in each vertical zBoard



2 Remove the adhesive strips on vertical zBoard



3 Starting from the bottom, join the vertical zBoards to the horizontal zBoards as shown

• Make sure zBoard surfaces are clean and dry.

• Assemble zBoards in 70-100° F (21-38° C) temperatures, and let the furniture rest for 24 hours before use, for optimal results.

• Furniture is for indoor use only.

• When moving your Way Basics furniture, lift from the bottom.

• zBoards are water-resistant, but you should place furniture on dry surfaces only.